

Cover Catch Installation

Step #1

Position each Cover Catch on side of Spa. Locate Cover Catch's a minimum of 12 Inches from ground and spaced 24 to 36 Inches apart. Orient Cover Catch as shown. (See Fig. 1)

Step #2

Attach Cover Catch to side of Spa using 6 #10 X 1" screws. Repeat for second Cover Catch. (See Fig. 1) Place Beauty Cap over screw heads after tightening screws.

Figure 1

